


RØROSHETTA


EN	INSTALLATION MANUAL
NO	INSTALLASJONSVEILEDNING
SV	INSTALLATIONSHANDBOK
DA	INSTALLATIONSVEJLEDNING
FI	ASENNUSOHJEET




CRYSTALL 1160/2
CRYSTALL 1180/2
CRYSTALL 1160
CRYSTALL 1180




- EN** Warning! Before proceeding with installation, read the safety information in the User Manual.
- NO** Advarsel! Les sikkerhetsinstruksjonene i bruksveiledningen før apparatet installeres.
- SV** Varning! Läs säkerhetsföreskrifterna i bruksanvisningen innan apparaten installeras.
- DA** Advarsel! Læs sikkerhedsreglerne i brugsanvisningen inden installation.
- FI** Varoitus! Ennen laitteen asentamista lue käyttöoppaassa olevat turvallisuustiedot.



L = 4x
(4,2x44,4)




F = 2x




P



H1 = 2x




P2 = 4x
(4x15)





P6 = 2x
(2,9x12,7)








O






P4 = 2x
(4,2x12)




F1








1A




1B




1C



2



3



4

