



If you have an iPhone or iPad you can download the latest version of the RørosHetta app to keep track of your Sense kitchen hood. If you have an android the app is called Safera.

The update is visible as long as you are connected to the kitchen hood.



If it doesn't show automatically you can locate it under "Firmware update".



We recommend you check for any error messages after updating your app.

You usually have to wait 30 minutes after updating to view any error messages.

Click on the three bars/hamburger menu in the top right corner.

Select "Sensor information", take a screen shot and send to service@roroshetta.no for further assistance.